




● Thank you for purchasing our product. Before installing/operating the product, please read the instructions carefully and retain them for future reference.

**⚠ Attention!**

- For installation, please follow the steps described. Any damage caused by wrong installation shall be imputed to the users.
- To avoid a short circuit from occurring do not pull or modify the wires during installation.
- Do not disassemble or change any parts. Opening and disassembling this unit will void any warranty.
- Maintenance and repairs should be executed by our professionals only.



⊗ Symbol description:

**NOTE**

⚠ Some procedures must be followed to avoid damages to the product.

⚠ **WARNING!** Certain procedures must be followed to avoid damages to yourself, to the vehicle or others.

**1 Accessories**


<p><b>1</b> Meter X1</p>	<p><b>2</b> Main wiring harness X1</p>	<p><b>3</b> RPM wire (TYPE A) X1</p>	<p><b>4</b> RPM wire (TYPE B) X1</p>
<p><b>5</b> External button X1</p>	<p><b>6</b> Gasket X1</p>	<p><b>7</b> Washer X1</p>	<p><b>8</b> Nut X1</p>
<p><b>9</b> Meter bracket X1</p>	<p><b>10</b> M5 washer X2</p>	<p><b>11</b> M5 Anti-slip nut X2</p>	<p><b>12</b> Oxygen sensor X1</p> <p>Bosch LSU 4.9</p>
<p><b>13</b> Sensor bung X 1</p>	<p><b>14</b> V type Meter bracket x 1 set</p>	<p><b>15</b> Handle bar clamp and rubber x 1</p>	<p><b>16</b> M6 x 18L mm screw x 1</p>
<p><b>17</b> M6 x P1.0 mm nut x 1</p>	<p><b>18</b> M6 washer x 1</p>	<p><b>19</b> Aluminum bushing x 1</p>	<p><b>1-2 Optional accessory</b></p> <p><b>1</b> Sensor adapter X1 (For 2 strokes engine only!)</p>

**2-0 Oxygen sensor installation**

1. Drill a 22mm (7/8") hole in the exhaust system at 20cm away from the exhaust flange.
2. Weld the sensor adapter to the muffler.
3. Install the oxygen sensor adapter. (For 2-stroke engine only!)
4. Install the oxygen sensor into the adapter.

**NOTE** If the meter is used on a 4-stroke engine. Please skip step3.


## 2-1 Wiring installation instructions



**NOTE** When connecting the power wire, please follow the instructions carefully.  
If the red & brown wires are connected in parallel, the meter will not work properly.

- ⚠ The RPM wire installation  
We recommend installing R type spark plugs or low-resistance spark plug caps at the same time.
- Connect the RPM wire (Type A) on the spark plug wire by connecting the male and female connectors.
  - Connect the RPM wire (Type B) to the pick up sensor.
  - Connect in parallel the RPM wire (Type A) with the original tachometer signal wire.
- The best signal source will be in order as C>B>A, we suggest that you try a different way if you have problems getting the RPM signal.**

## 2-2 Installation instructions




When installing, please follow the steps below.

- Meter x1 (Accessory 1)
- Vehicle

**NOTE** An opening must be made in the vehicle, with a size  $\geq 64$  mm.

- Meter bracket x1 (Accessory 9)
- M5 washer x2 (Accessory 10)
- M5 Anti-slip nut x2 (Accessory 11)

## 2-3 Installation instructions




When installing, please follow the steps below.

- External button x1 (Accessory 5)
- Gasket x1 (Accessory 6)
- Vehicle

**NOTE** An opening must be made in the vehicle, with a size  $\geq 12$  mm.

- Washer x1 (Accessory 7)
- Nut x1 (Accessory 8)

### 3-1 Basic function instruction



**Tachometer**

- Display Range : 0 ~ 14,000 RPM
- Display unit : 100 RPM
- Tachometer (Displays in segments)
- Display Range : Displays in 14 segments (100 RPM each segment)
- Air-fuel ratio
- Display Range : 9.0 ~ 24.0
- Display unit : 0.1
- Air-fuel ratio (Displays in segments)
- Display Range : Displays in 12 segments

**Max. RPM**

- Display Range : 0 ~ 14,000 RPM
- Max. Air-fuel ratio (value of ratio) record
- Display Range : 9.0 ~ 24.0
- Max. Air-fuel ratio (  $\lambda$  ) record
- Display Range : 0.61 ~ 1.63

**Play mode Speed**

- 1x play/pause 
- 1/3x play/pause 
- 3x play/pause 
- 1x rewind/pause 

**Type of RPM signal**

- Setting range : Hi Act \ Lo Act
- Warning for RPM
- Setting range : 1,000 ~ 14,000 RPM
- Setting unit : 100 RPM
- Warning for low voltage
- Setting range : 8.0 ~ 13.0 V
- Setting unit : 0.1 V
- Backlight brightness
- Setting range : 1 - 5 (darkest)~ 5 - 5 (brightest)

**Record**

- Maximum number of recorded runs: 50 runs
- Maximum recording time for a single record run: 99m 59s 90; the recording will stop upon reaching the maximum time.
- Total recording time: Approximately 3.15 hours

**Maximum RPM and air-fuel ratio for a single run**


- Scope of recording for RPM : 0 ~ 14,000 RPM
- Air-fuel ratio (value of ratio) record : 9.0 ~ 24.0
- Air-fuel ratio (  $\lambda$  ) record : 0.61 ~ 1.63

### 3-2 Features and settings description

● Tachometer	Display Range : 0 ~ 14,000 RPM Display unit : 100 RPM	● Air-fuel ratio	Display Range : 9.0 ~ 24.0 Setting unit : 0.1
● Tachometer (Display in segments)	Display Range : Displays in 14 segments (100 RPM each segments)	● Warning for Rich air-fuel ratio	Setting range : 9.0 ~ 14.7 Setting unit : 0.1 Default value : 14.4
● RPM input pulse	Setting range : 0.5 . 1 . 1.5 . 2 . 2.5 . 3 . 4 . 5 . 6 . 7 . 8 . 9 . 10 . 11 . 12 . 13 . 14 . 15 . 16 . 17 . 18 . 19 . 20 . 21 . 22 . 23 . 24	● Warning for Lean air-fuel ratio	Setting range : 14.7 ~ 24.0 Setting unit : 0.1 Default value : 15.0
● Type of RPM signal	Setting range : Hi Act \ Lo Act Default value : Hi Act	● Air-fuel ratio (display segments)	Display Range : Displays in 12 segments
● Warning for RPM	Setting range : 1,000 ~ 14,000 RPM Setting unit : 100 RPM Default value : 8,000	○ Operating voltage	DC 12V
● Warning for low voltage	Setting range : 8.0 ~ 13.0 V Setting unit : 0.1 V Default value : 11.5 V	● Temperature range	-10 ~ +60°C
● Backlight brightness	Setting range : 1 - 5 (darkest)~ 5 - 5 (brightest) Default value : 5	○ Specifications	JIS D 0203(S2)
		● Meter Size	72 X 32.3 mm
		○ Meter Weight	About 100 g

**NOTE** Design and specifications may change without further notice.

### 3-3 Meter size



## 4-1 Description of Warnings

### • Warning for rich air-fuel ratio



$\leq$  Warning value  
Default value : 14.4



$\leq$  Minimum display value 9.0

### • Warning for lean air-fuel ratio



$\geq$  Warning value  
Default value : 15.0



$\geq$  Maximum display value 24.0

### • Warning for RPM



$\geq$  Warning value  
Default value : 8,000 RPM



$\geq$  Maximum display value 14,000 RPM

### • Warning for low voltage



$\leq$  Warning value 10 seconds  
Default value : 11.5 V

## 4-2 Description of Select Button Function



- |                |
|----------------|
| RPM            |
| Air-fuel ratio |
| Voltage        |

 screen, press the select button once to switch to
 

Air-fuel ratio
RPM
Voltage

- Hold the select button for 3 seconds, and the display of air-fuel ratio shifts from the value of ratio to  $\lambda$  value.



- |                |
|----------------|
| Air-fuel ratio |
| RPM            |
| Voltage        |

 screen, press the select button once to switch to
 

MAX
RPM
Air-fuel ratio
X



- |                |
|----------------|
| MAX            |
| RPM            |
| Air-fuel ratio |
| X              |

 screen, press the select button once to return to
 

RPM
Air-fuel ratio
Voltage

- Hold the adjust button for 3 seconds, to clear the MAX recording screen.



- |                |
|----------------|
| RPM            |
| Air-fuel ratio |
| Voltage        |

 screen.

## 4-3 Description of Adjust Button Function



- Air-fuel ratio screen, **press the adjust button once** to switch to the recording screen.
- Hold the adjust button for 3 seconds, and the Bar display shifts from RPM to air-fuel ratio.



- At the recording screen, **press the adjust button once** to switch to the play screen.
  - Press the external button once, to enter the setting for the recording screen.
- NOTE** Please refer to 3-6 Setting.



- The playing screen, **press the adjust button once** to return to Air-fuel ratio screen.
  - Press the select button once to enter the play screen.
- NOTE** Please refer to 3-7 Setting.



- RPM Air-fuel ratio Voltage screen.

## 4-4 Operating Description of the Recording Screen



- Main screen, **press the adjust button once** to enter the recording screen.



- The recording screen, **press the external button once** to start recording.
- NOTE** Hold the External button for 3 seconds, to enter the operating screen for clearing records.



- At the screen during recording, **press the External button once** to stop recording.
- The first run has been recorded.



- To stop the recording screen, **press the External button once** to enter the recording screen for the second entry.



- Prepare to enter the recording screen for the second entry.



- Currently it is in the recording screen for the second entry.



- Currently it is in the recording screen for the third entry.



- Currently it is in the recording screen for the fourth entry.



- At the recording screen for the fifth entry, press the External button twice to return to the main screen.



- Main screen.

## 4-5 Operating Description for the Play Screen



- Main screen, **press the adjust button twice** to enter the play screen.



- The playing screen, **press the select button once** to enter the screen of the highest RPM for the period of the recorded run.



- At the screen of the highest RPM, **press the adjust button once** to choose the run to be played.
- NOTE** Hold the select button for 3 seconds, to immediately slow down the play screen.



- To select the fourth run for playing, **press the adjust button once** to enter the play / stop screen.
- NOTE** At any point, hold the adjust button for 3 seconds, to return to the main screen.



- At the recording screen of the fourth run, **press the select button once** to start playing at normal speed.



- At the end of playing the entry at normal speed, **press the adjust button once** to enter the screen of playing at 1/3 speed.



- At the end of playing at 1/3 speed, **press the adjust button once** to enter the screen of playing at 3x speed.



- At the end of playing at 3x speed, **press the adjust button once** to enter the reverse screen.



- At the end of playing the reverse screen, **press the adjust button once** to return to the screen for maximum RPM.



- At the screen of maximum RPM, hold the adjust button for 3 seconds to return to the main screen.



- Main screen.

## 4-6 Operating Description for Clearing Records



- At the main screen, **press the Adjust button** once to enter the recording screen.



- Clearing complete; wait for a few seconds to return to the recording screen.



- The recording screen.



- At the recording screen, **hold the External button** for three seconds to enter the operating screen for clearing records.


- The recording screen may also be cleared.



- Clearing the record; wait for a few seconds to complete clearing.

**NOTE** Where there is no record to be cleared, press either "Adjust," "Select," or "External" button to return to the recording screen.


## 5 The Settings Screen Description




•Main screen



•Setting screen



•Warning for RPM



•Warning for rich air-fuel ratio

- In the main screen, **hold the Adjust button and the select button for 3 seconds** to enter the setting screen.


- Press the Select button** to select the desired setting screen.

In order; Warning for RPM · Warning for rich air-fuel ratio · Warning for lean air-fuel ratio · Warning for low voltage · Backlight brightness · RPM input pulse · Type of RPM signal.


**NOTE** If you enter the settings screen and don't press any buttons for 30 seconds, it will automatically return to the main screen.




•Warning for lean air-fuel ratio




•Type of RPM signal



•RPM input pulse



•Backlight brightness



•Warning for low voltage

### 5-1 Over RPM Warning Setting



- In the main screen, **hold the adjust button and the select button for 3 seconds** to enter the over RPM warning setting.



- Press the select button** to choose the setting number.



- EX** : To set the over RPM warning value to 9,000 RPM.
- Press the select button once** to choose the setting number.

⚠ Now the setting value will blink.

**NOTE** Setting range : 1,000 ~ 14,000 RPM  
Setting unit : 100 RPM  
Default value : 8,000 RPM.




- Example** : Set the over RPM warning setting value from 8,000 RPM to 9,000 RPM.
- Press the select button twice** to enter the Warning for rich air-fuel ratio.




- Warning for rich air-fuel ratio screen.

## 5-2 Warning For Rich Air-Fuel Ratio Setting




- EX : To set the warning for rich air-fuel ratio value to 12.5.
  - Press the select button once to choose the setting number.
- ⚠ Now the setting value will blink.

**NOTE** Setting range : 9.0 ~ 14.7  
Setting unit : 0.1  
Default value : 14.4



- Press the adjust button to choose the setting number.



- Example : Set the warning for rich air-fuel ratio value from 14.4 to 12.5.
- Press the select button twice enter the warning for lean air-fuel ratio.




- Warning for lean air-fuel ratio screen.

## 5-3 Warning for lean air-fuel ratio Setting



- EX : To set the warning for lean air-fuel ratio value to 19.5
  - Press the select button once to choose the setting number.
- ⚠ Now the setting value will blink.

**NOTE** Setting range : 14.7 ~ 24.0  
Setting unit : 0.1  
Default value : 15.0



- Press the adjust button to choose the setting number.



- Example : Set the warning for lean air-fuel ratio ratio value from 15.0 to 19.5.
- Press the select button once enter the warning for warning for low voltage.




- Warning for low voltage screen.

## 5-4 Warning For Low Voltage Setting




- EX : To set the warning for low voltage value to 10.5.
  - Press the select button once to choose the setting number.
- ⚠ Now the setting value will blink.

**NOTE** Setting range : 8.0 ~ 13.0 V  
Setting unit : 0.1 V  
Default value : 11.5 V



- Press the adjust button to choose the setting number.



- Example : Set the warning for low voltage value from 11.5 V to 10.5 V.
- Press the select button once to enter the warning for backlight brightness.



- Backlight brightness screen.

## 5-5 Backlight Brightness Setting



- EX : To set backlight brightness value to 3/5.
  - Press the adjust button once to choose the setting number.
- ⚠ Now the setting value will blink.

**NOTE** Setting range : 1/5 ~ 5/5  
Setting unit : 1/5  
Default value : 5/5




- Example : Set the backlight brightness value from 5/5 to 3/5.
- Press the select button once to enter the warning for RPM input pulse



- RPM input pulse screen.


## 5-6 RPM Input Pulse Setting



- **EX.** You want to connect the RPM signal wire to the pick up signal and there are 12 flywheel signals per turn.
- Press the adjust button once to choose the setting number.

⚠ Now the setting value will blink.

**NOTE** Setting range : P-0.5 , P-1 , P-1.5 , P-2 , P-2.5 , P-3 , P-4 , P-5 , P-6 , P-7 , P-8 , P-9 , P-10 , P-11 , P-12 , P-13 , P-14 , P-15 , P-16 , P-17 , P-18 , P-19 , P-20 , P-21 , P-22 , P-23 , P-24  
Default value : P-1




- Example : Set the RPM input pulse value from P-1 to P-12.
- Press the select button once enter the type of rotation speed signal.



- Type of RPM signal screen.

## 5-7 Type Of RPM Signal Setting



- **EX :** To set type of RPM signal value to Lo Act.
- Press the adjust button once to choose the setting number.

⚠ Now the setting value will blink.

**NOTE** Setting range : Hi Act , Lo Act  
Default value : Hi Act



- Main screen.



- Example : Set the type of RPM signal from Hi Act to Lo Act.
- Press the select button once to return to the main screen.

## 6 Trouble shooting

The following situations do not necessarily indicate malfunction of the product. Please check the following points, before contacting us.

Trouble	Check item	Trouble	Check item
<p>The meter doesn't work when the power is on.</p> <p>The meter shows wrong information.</p> <p>Tachometer doesn't appear or appears incorrectly.</p>	<ul style="list-style-type: none"> <li>● The power isn't supplied to the meter. → Please make sure the wiring is connected. The wiring and fuse are not broken.</li> <li>→ The battery is too old to supply needed power (DC 12 V).</li> <li>● Check the voltage of your battery, and make sure the voltage is over DC 12 V.</li> <li>● May be due to poor connection of wires. → Please check whether the wiring is disconnected or has fallen off.</li> <li>● May be due to the failure to change to the type R spark plug.</li> <li>● May be wrong settings. → Please check the settings menu to confirm whether the setting for RPM is correct.</li> </ul>	<p>Voltage doesn't appear or appears incorrectly.</p> <p>A / F does not display or displays error.</p>	<ul style="list-style-type: none"> <li>● Wiring for the connector may be poorly installed. → Please confirm whether the wires for the connector are properly installed.</li> <li>● May be due to poor connection of wires. → Please check whether the wiring is disconnected or has fallen off.</li> <li>● May be due to the wrong setting of AFR. → Please check the settings menu to confirm whether the setting is correct.</li> </ul>

※If the problems still can't be solved, please contact our technical department for assistance.